


STEP 1-REMOVE THIS SECTION FROM THE POLYETHYLENE BALL BY REMOVING THE TWO THUMBSCREWS AND PULLING THIS SECTION OUT BY THE CLIPS.

STEP 2-REMOVE THE SETSCREW FROM THE SIDE WITH A 1/8" ALLEN HEX WRENCH.

STEP 2 SETSCREW


DWN DATE CHK DATE	₽₽	APP DATE
0/30/06		
DWG NUM: 4005-023	SCALE: FULL OTHER	ULL Ø THER
TITLE M 42-31 BF3 TUBE REMOVAL	BE REM	OVAL
LUDLUM MEASUREMENTS, INC.	SERIES	SHEET
SVEETVATER, TEXAS 79556	ഗ	17B



STEP 4-REMOVE SCREW FROM END OF POLYBALL ASSEMBLY AND REMOVE POLYBALL ASSEMBLY. THE COLLAR USING A 1/16 ALLEN HEX WRENCH

STEP 6-REMOVE AND REMOVE COLLAR.
-REMOVE 2-56 SCREWS (3 EA.)
-REMOVE 4-40 SCREWS (3 EA.) FROM TUBE HOUSING,

	TITLE	DWG	DWN DATE
LUDLUM NEASUREMENTS, INC. 501 DAK STREET SVEFT WATER. TEXAS 79556	E M 42-31 TUBE REMOVAL	DWG NUM: 4005-023)/30/06
ENTS, INC.	TUBE F	023	CHK DATE
SERIES 5	KEMOV	SCALE: FULL OTHER	
	AL	물글	APP
SHEET 17C		ER Ø	APP DATE



STEP 8-REMOVE ENDCAP ASSEMBLY, NEUTRON TUBE AND INTERNAL SPACER FROM TUBE HOUSING.
STEP 9-UNSOLDER THE WIRES FROM NEUTRON TUBE AND DISPOSE OF NEUTRON TUBE PER LOCAL,
STATE AND FEDERAL REGULATIONS.
STEP 10-REASSEMBLE THE DETECTOR WITHOUT THE NEUTRON TUBE IN REVERSE ORDER AND SHIP
THE MODEL 42-31 WITH THE MODEL 12-4 BACK TO

_UDLUM MEASUREMENTS INC.

ATTEN: REPAIR DEPARTMENT

501 □AK ST.

SWEETWATER TX 79556

NO RMA NUMBER IS NEEDED BUT A NOTE WITH A CONTACT NAME AND PHONE NUMBER IS.